

Auxiliary Keypad Unit



All devices are connected to a master unit which has a built in transmitter.

Master Keypad Unit



Gate/Entrance 1

- Up to 6 auxiliary units can be connected to a master unit: Relay 1 and 2 on master unit; relays 3 to 8 on auxiliary units.
- Can have a mix of keypads & prox reader units in one set up.
- DDA LEDS on each auxiliary unit indicates correct or incorrect code/card used.
- Relay on every auxiliary unit that can be set via a dip switch.
- Keypad tones/ confirmation sound can be adjusted on auxiliary units.
- Units are wired via 5 cores of cat 5 cable.



Gate/Entrance 2

Gate/Entrance 3

Gate/Entrance 4



Auxiliary Prox Reader Unit

Auxiliary Prox & Keypad Unit



AES



Now compatible with our AES PRO APP. With our pro app it's now easier to programme and have control over multiple units (sites) all from your mobile.

AES

PR∰

Technical Details	
Power	24v d.c
Current	300mA/2A Peak 100mA Per Auxiliary Unit
Weather Rating	IP55
Relay Type	2 x N/C & N/O Contacts
Total Permanent Keypad Codes	250
Total Permanent Prox Cards	250
Time Restricted Codes/Cards	250
Temporary Codes/Cards	50



Area code: EU (Europe) US (USA) AU (Australia & NZ)

Master Units: Keypads, Prox readers with built in transmitter.



KEY-MST-PBPK-EU

Master unit with keypad & prox reader.




KEY-MST-PBK-EU

Master unit with keypad.



KEY-MST-PBP-EU

Master unit with prox reader.



Auxiliary Pedestal Keypads & Prox readers.



KEY-AUX-PBPK-EU

Aux pedestal unit with keypad & prox reader.




KEY-AUX-PBK-EU

Aux pedestal unit with keypad.



KEY-AUX-PBP-EU

Aux pedestal unit with prox reader.



Auxiliary Keypads & Prox readers.



KEY-AUX-IBPK-EU

Aux unit with keypad & prox reader.



KEY-AUX-IBK-EU

Aux unit with keypad.



KEY-AUX-IBP-EU

Aux unit with prox reader.

