




Auxiliary Keypad Unit

Master Keypad Unit




Gate/Entrance 2



All devices are connected to a master unit **which has a built in transmitter.**



Gate/Entrance 1




Gate/Entrance 3

Auxiliary Prox Reader Unit



- Up to **6 auxiliary units can be connected** to a master unit: Relay 1 and 2 on master unit; relays 3 to 8 on auxiliary units.
- Can have a mix of keypads & prox reader units in one set up.
- DDA LEDS on each auxiliary unit indicates correct or incorrect code/card used.
- Relay on every auxiliary unit that can be set via a dip switch.
- Keypad tones/ confirmation sound can be adjusted on auxiliary units.
- Units are wired via 5 cores of cat 5 cable.



Gate/Entrance 4

Auxiliary Prox & Keypad Unit



Technical Details

| | |
|-------------------------------------|---|
| Power | 24v d.c |
| Current | 300mA/2A Peak 100mA Per Auxiliary Unit |
| Weather Rating | IP55 |
| Relay Type | 2 x N/C & N/O Contacts |
| Total Permanent Keypad Codes | 250 |
| Total Permanent Prox Cards | 250 |
| Time Restricted Codes/Cards | 250 |
| Temporary Codes/Cards | 50 |



Area code:
EU (Europe)
US (USA)
AU (Australia & NZ)

Master Units: Keypads, Prox readers with built in transmitter.



KEY-MST-PBPK-EU

Master unit with keypad & prox reader.




KEY-MST-PBK-EU

Master unit with keypad.



KEY-MST-PBP-EU

Master unit with prox reader.



Auxiliary **Pedestal** Keypads & Prox readers.



KEY-AUX-PBPK-EU

Aux pedestal unit with keypad & prox reader.




KEY-AUX-PBK-EU

Aux pedestal unit with keypad.



KEY-AUX-PBP-EU

Aux pedestal unit with prox reader.



Auxiliary Keypads & Prox readers.



KEY-AUX-IBPK-EU

Aux unit with keypad & prox reader.




KEY-AUX-IBK-EU

Aux unit with keypad.



KEY-AUX-IBP-EU

Aux unit with prox reader.



All black panels with textured powder coated aluminium hood and gloss acrylic faceplate. Keypad panels have illuminated buttons.